

We at Barronett Blinds appreciate your purchase of one of our world class Hub Blinds. Follow these few simple instructions and your Hub Blind will be sure to give you many years of trouble-free pleasure. Instructions should be kept safe and reviewed at least annually.

If for any reason you have a problem with your product, DO NOT return to the retailer; contact the Barronett Blinds customer service department at 800-345-6007, Monday through Friday from 8 a.m. to 5 p.m., for assistance.

SET-UP INSTRUCTIONS:

1. Remove the ground blind from backpack carrying bag.

2. Lay the blind flat on the ground and be completely sure there is no material twisted or overlapping the ends of any poles. **SEE FIGURE 1.**




FIGURE 1




FIGURE 2




FIGURE 3

3. Grab the pull handle on the eyelet located in the center of the roof and pull upward so the roof portion pops open. **SEE FIGURE 2.**

4. Lift the roof up so that you can grab any one of the hubs located in the center of each wall. Grab the tie-down rope on the eyelet and pull out as you did in step 3. **SEE FIGURE 3.**

NOTE: Place your foot on the ground skirt to help hold the blind in place when popping open the walls. (Ground skirt is not included in all models).

5. Proceed by walking around entire blind and pulling on each of the wall's tie-down ropes to pop out each wall until all sides are popped out. **SEE FIGURE 4.**




FIGURE 4

6. Your blind should be standing up completely. You may now proceed by anchoring the blind to the ground using the ground stakes and tie-down ropes provided. Ground stakes for your Barronett Blind are located in a pouch inside of the blind. The pouch is sewn in at ground level onto the interior wall near the door. Anchor loops are sewn in each corner and each side. Use the provided tie-down ropes and tie free end to ground stake. **SEE FIGURE 5.**




FIGURE 5

NOTE: Window configurations can now be set. Native brush can be placed in brush holders located around the blind. (Brush holders not included on all models.)

ASSEMBLY AND USE INSTRUCTIONS FOR THE FOLLOWING MODELS:

SNAKE EYES (SE250BA, SE250BW, SE350BA, SE350BW)
GROUNDER (GR150BT, GR250BT, GR350BT)
BIG MIKE (BM275BT)

! WARNING

READ, UNDERSTAND AND FOLLOW ALL ASSEMBLY, INSPECTION, AND USE INSTRUCTIONS PROVIDED BEFORE EACH USE. FAILURE TO FOLLOW WARNINGS AND INSTRUCTIONS COULD RESULT IN SERIOUS INJURY OR DEATH.

KNOW THE LOCATION OF EACH HUNTER IN YOUR PARTY AT ALL TIMES AND BE AWARE OF ANY ONE ELSE HUNTING IN THE AREA TO AVOID ACCIDENTS.

USE CAUTION WHEN SETTING UP. KEEP AWAY FROM BODY AND FACE. KEEP CLEAR OF OTHER PEOPLE WHILE SETTING UP.

THIS PRODUCT IS NOT FIREPROOF. THE FABRIC WILL BURN IF IT COMES INTO CONTACT WITH AN OPEN FLAME OR FUEL SOURCE. NO HEATER OR OPEN FLAME SHOULD BE USED INSIDE OR NEAR THIS BLIND.

NEVER ALLOW CHILDREN OR ADULTS TO USE LIGHTED CANDLES, MATCHES, OR OTHER SOURCES OF FIRE NEAR THIS PRODUCT.

NEVER USE ANY DEVICES THAT PRODUCE FUMES WHILE INSIDE OF BLIND. SUCH DEVICES COULD RESULT IN CARBON MONOXIDE POISONING, INJURY, OR DEATH.

WHEN GUN HUNTING, YOU SHOULD ALWAYS ATTACH THE BLAZE ORANGE SAFETY CAP (NOT INCLUDED) PART NO. AV180 TO THE ROOF OF BLIND FOR ADDED SAFETY FROM OTHER HUNTERS.

! UV WARNING

ULTRAVIOLET LIGHT BREAKS DOWN LIGHTWEIGHT FABRIC FIBERS. THE MATERIAL WILL FADE, LOSE STRENGTH AND EVENTUALLY DISINTEGRATE IF LEFT IN PROLONGED SUNLIGHT. TO EXTEND THE LIFE OF YOUR GROUND BLIND, AVOID LEAVING IT OUT IN DIRECT SUNLIGHT FOR EXTENDED PERIODS OF TIME. SET IT UP IN A SHADY AREA WHENEVER POSSIBLE. FADING OR DISCOLORING OF BLIND IS NOT COVERED UNDER YOUR WARRANTY.

TAKE-DOWN INSTRUCTIONS:

1. Remove all ground stakes and store them in the provided pouch (tie-down ropes should stay tied to the hub eyelits). Close all windows. Remove all native brush (if applicable).
2. Using your hand, push the center hub in on roof and walls until they collapse inward. **SEE FIGURES 6 & 7.**




FIGURE 6




FIGURE 7

3. Blind will be back in its flat stage just as it was when it was unfolded out of the backpack bag. Gather all corners of the blind and fold together. **SEE FIGURE 8.** Do not force the blind when folding. Watch for entanglement of poles.
4. Place folded blind back into the backpack carrying case with the hubs towards the bottom end of bag always.




FIGURE 8

MAINTENANCE INSTRUCTIONS:

1. Never put blind away wet. Always put away dry to avoid mildew.
2. Take down blind when not in use to avoid unnecessary damage and fading.
3. Seal the seams with seam sealer and the walls and roof with silicon spray if leaking occurs.
4. Use extra tie-downs during excessive winds.



WARNING

READ, UNDERSTAND AND FOLLOW ALL ASSEMBLY, INSPECTION, & USE INSTRUCTIONS PROVIDED BEFORE EACH USE. FAILURE TO FOLLOW WARNINGS AND INSTRUCTIONS COULD RESULT IN SERIOUS INJURY OR DEATH.

THIS PRODUCT IS FOR HUNTING PURPOSES ONLY! IT IS NOT TO BE USED AS A CAMPING TENT OR FOR ANY OTHER FUNCTION.

THIS BLIND IS DESIGNED FOR PORTABILITY. DO NOT LEAVE BLIND SETUP OUTDOORS WHEN NOT IN USE.

DO NOT USE FIREARMS TO SHOOT THROUGH THE REMOVABLE SHOOT-THROUGH MESH WINDOWS. THE SHOOT-THROUGH WINDOWS ARE INTENDED FOR ARCHERY USE WITH FIXED BLADE BROAD HEADS ONLY!

NEVER ALLOW CHILDREN TO PLAY IN THIS PRODUCT WITHOUT ADULT SUPERVISION. TO DO SO COULD CAUSE SERIOUS INJURY OR DEATH.

NEVER ALLOW THE MATERIAL TO COVER YOUR FACE. THIS MATERIAL CAN CAUSE SUFFOCATION AND DEATH IF IT IS PLACED OVER FACE.

ONE YEAR LIMITED WARRANTY

Ardisam, Inc., a manufacturing company, warrants this Barronett Ground Blind to be free from defects in the material or workmanship for a period of one year from the date of purchase. During the one year warranty of this product, Ardisam will furnish 100% parts and labor to correct any defect caused by faulty material or workmanship. **The warranty does not cover fading or discoloring of camo fabric, tent tears, or broken poles due to high wind conditions or unattended use.** Warranty work must be sent directly to Ardisam, Inc. or to an authorized service center. **To obtain warranty service and/or replacement instructions, you must have prior approval before shipping package by calling our customer service department at 1-800-345-6007 Monday through Friday from 8 a.m. to 5 p.m. for a return material authorization number (RMA#).** All items must be shipped prepaid. Ardisam, Inc. will at no charge, repair or replace, at their discretion, any defective part which falls under the conditions stated above. Ardisam retains the right to change models, specifications and price without notice. This product if used as intended, will give you years of trouble free service. We hope you will enjoy the quality of our products for years to come. **For replacement parts, phone 1-800-345-6007 or go online to BarronettBlinds.com.**

This warranty applies to the original owner with a proof of purchase and is not transferable. It supersedes all other warranties either expressed or implied and all other obligations to liabilities on our part. Ardisam, Inc. does not assume, and does not authorize any other person to assume for us, any liability in connection with the sale of our products. The warranty applies only to products which have not been subjected to negligent use, misuse, alteration, accident or repairs made by anyone not certified by Ardisam, Inc. This guarantee is void unless the warranty card is properly filled out and received by Ardisam, Inc., within 30 days of purchase.

HUB BLIND COMPONENTS:

WINDOWS

- 45001 WINDOW, MESH, GR150BT, 20" X 46"
- 45004 WINDOW, MESH, GR250BT, 23" X 54"
- 45006 WINDOW, MESH, GR350BT, 28" X 65"
- 45008 WINDOW, MESH, BM275BT, LEFT
- 45009 WINDOW, MESH, BM275BT, CENTER
- 45010 WINDOW, MESH, BM275BT, RIGHT
- 45012 WINDOW, MESH, SE250BA, LEFT
- 45013 WINDOW, MESH, SE250BA, CENTER
- 45014 WINDOW, MESH, SE250BA, RIGHT
- 45016 WINDOW, MESH, SE350BA, LEFT
- 45017 WINDOW, MESH, SE350BA, CENTER
- 45018 WINDOW, MESH, SE350BA, RIGHT
- 45020 WINDOW, MESH, SE250BW, LEFT
- 45021 WINDOW, MESH, SE250BW, CENTER
- 45022 WINDOW, MESH, SE250BW, RIGHT
- 45024 WINDOW, MESH, SE350BW, LEFT
- 45025 WINDOW, MESH, SE350BW, CENTER
- 45026 WINDOW, MESH, SE350BW, RIGHT

BACKPACK CARRYING CASES

- 48706 BACKPACK, GROUND 150
- 48712 BACKPACK, GROUND 250
- 48718 BACKPACK, GROUND 350/BIG MIKE 275
- 48506 BACKPACK, SNAKE EYES 250 WEST
- 48507 BACKPACK, SNAKE EYES 350 WEST
- 48902 BACKPACK, SNAKE EYES 250 ADRENALINE
- 48903 BACKPACK, SNAKE EYES 350 ADRENALINE

POLES, STAKES AND ROPE

- 48701 POLE FIBERGLASS 37" (150 models)
- 48707 POLE FIBERGLASS 42" (250 and 275 models)
- 45027 POLE FIBERGLASS 46" (275 models)
- 48713 POLE FIBERGLASS 49.5" (350 models)
- 48722 GROUND STAKE
- 48723 TIE-DOWN ROPE

HUB BLIND ACCESSORY:

- AV180 BLAZE CAP

*Left and right window panels are determined by looking at the windows from the "in-use" position from inside of the blind.

*All weights, specifications and features are approximate and are subject to change without notice. Due to continuous product improvements, product images may not be exact. Warning labels in some product images may have been removed for photography purposes only. Props shown in photos not included. Some assembly may be required.

BarronettBlinds.com

800-345-6007 • Fax (715) 822-4180
E-mail: info@ardisam.com



BarronettBlinds.com

Barronett Blinds, Division of Ardisam, Inc.
1160 Eighth Ave; P.O. Box 666
Cumberland, Wisconsin 54829